

GELCO MULTI-FLUE & SEMI-CUSTOM CAPS

Installation Instructions

1. Always wear gloves when installing or handling chimney tops. If the cap is preassembled (not a knock-down top) **proceed to step 4.**

2. Assemble the base by aligning the loose mesh panel hinges with the three sided mesh panel hinges. Then insert the hinge pins. When assembling the base, the narrow lid mounting top strips *always face in.*

3. Attach the lid using the cap screws and washers. Simply position the lid on the base, and bolt the lid down.

4. Place the top on the crown, positioning the SwingTab™ Reversible Mounting Strips, as determined by the crown dimensions. Center and level the top.

5. Once you've determined the position of the top, mark a placement line around the top on the chimney crown using a grease pencil, chalk, etc.

7. **SwingTabs out:** Set the tabs down onto the chimney crown, making sure the base stays aligned with your placement line.

SwingTabs in: Remove the lid. Place the base on the crown making sure the base stays aligned with your placement line.

8. **Recommended.** Lift each hinged tab up and place a bead of adhesive equal to 1/4" - 1/2" (approximately 3/4" inside the placement line if the **SwingTabs are in**) on the bottom side. Press the tabs down into the adhesive, making sure the base stays aligned with your placement line. *(Note: Adhesive is sold separately - item #13910)*

9. Using one of the holes in the mounting tabs as a template, drill a hole into the chimney crown using a 3/16" masonry drill bit for the first tapcon screw. The holes should be a minimum of 1 1/2" deep. Install two masonry screws on two opposite sides or one on each of four sides. Repeat this process, installing tapcon screws until the top is secured. (Use a minimum of four screws.)

10. If necessary reattach the lid.

